FITTING A TIMBER FLOOR OVER TIMBER/CHIPBOARD SUBFLOOR

MARLDON

1 TIMBER / CHIPBOARD SUBFLOOR

2 M-321 SILVER UNDERLAY

The water vapour diffusion is valid when the butted joints are carefully taped using DPM Jointing Tape.

3 TIMBER FLOOR

Refer to Manufacturer for compatibility.



01772 696600 | info@marldonuk.com | www.marldonuk.com