FITTING A TIMBER FLOOR OVER TIMBER/CHIPBOARD SUBFLOOR

MARLDON

❶ TIMBER / CHIPBOARD SUBFLOOR

❷ K-527 GOLD ACOUSTIC UNDERLAY

The water vapour diffusion is valid when the butted joints are carefully taped, using DPM Jointing Tape.

❸ TIMBER FLOOR

Refer to Manufacturer for compatibility.



01772 696600 | info@marldonuk.com | www.marldonuk.com