FITTING A TIMBER FLOOR OVER A CONCRETE SUBFLOOR

❶ CONCRETE SUBFLOOR

❷ PROVENT 3MM UNDERLAY

Incorporates moisture barrier, compatible with underfloor heating. 20db impact noise reduction.

❸ PVA ADHESIVE

Apply as recommended by floor manufacturer.

❹ TIMBER FLOOR

Refer to Manufacturer for compatibility.



01772 696600 | info@marldonuk.com | www.marldonuk.com